

?? ????????????? ???? ?

???? ??????? 9,00 €

?????????

Antenna rod

acv basic

Style: 16V

The acv basic antenna range offers good reception performance even under less than ideal conditions thanks to the selection of quality components and careful installation.

To optimise the reception of antennas, always ensure an optimum ground connection of the antenna base or the ground strap during installation.

Remove existing paint at the contact points with workshop materials and protect against corrosion with suitable contact paste and also treat the antenna rod thread and the antenna base thread to optimise contact.

Note:

In case of reception problems:

check antenna cable and antenna adapter

check vehicle for faults due to retrofit LED lighting  
check vehicle for faults due to retrofit voltage converter / power supply units / USB charging adapter  
check vehicle for faults due to retrofit digital power amplifiers

Reception Mode:

AM/FM

Dimensions:

length: 15,5 cm  
thread: 6 mm internal  
adapter: M6>M5 / M6>M6 external